

# Setting up your projector, elmo and laptop

Look at the following diagrams to set up your projector, Elmo and notebook computer.

You will need five items: 1. your projector; 2. your Elmo; 3. your computer; and 4. two connecting cables. The two cables are the same on both ends, so it does not matter end you plug in.

What you need:

1. Your projector



2. Your Elmo

3. Your laptop



or computer




4. Two video cables

The steps to connect and activate the setup are:

1. Connect your Elmo to your projector – connect the first cable to the **RGB out** port on the Elmo with the picture of the projector and plug the cable into the port of the projector in your wall.

2. Connect your computer to the Elmo – connect the second cable to the **RGB in** port of your Elmo with the picture of the computer and plug the other end of the cable into the **video (screen icon)** port of the laptop or into the splitter connected to the computer.

Step 1: Connect the RGB OUT port on the Elmo to the COMPUTER IN port on the projector.



Step 2: Connect the RGB IN port on your Elmo to the VIDEO port on your computer.

You are not quite done. After you have connected the three components with the two cables, make sure to:

1. Power on the Elmo and press the **Document camera** button to project from your Elmo.
2. To switch from the Elmo to the computers, press the **Computer** button on the Elmo. The signal will then pass from the computer, through the Elmo to the projector.
3. To write on your interactive board (Smart, Numonics, Mimio) press the **Computer** button on the Elmo, then open Image Mate software on your computer.